

**PARTS LIST**

QTY.	DESCRIPTION
1	Speedometer Cowl
1	Alcohol Wipe



None Required

**PREPARATION**

Place the motorcycle securely on its side stand.  
Thoroughly clean the speedometer area before installing the Speedometer Cowl. **DO NOT** use polishes or silicones.

**INSTALLATION**

- 1. Before you remove tape liner**, determine the best mounting position by placing the Speedometer Cowl around speedometer.
- Use the Alcohol Wipe to clean the area where the Speedometer Cowl is to be installed.
- Remove the red backing from the adhesive on the underside of the Speedometer Cowl.
- Lightly** position the Speedometer Cowl in place around speedometer.
- When the Speedometer Cowl is satisfactorily positioned, firmly press the Cowl in place.
- Let adhesive tape set-up 4-6 hours before using motorcycle.

**MAINTENANCE**

Clean and polish with a chrome cleaner / polish.