

## Schutzplatte für Original-Hauptständer

BMW R 1200 GS LC  
Artikel-Nr.: 420.665-02

BMW R 1200 GS Adventure ab Bj.2014  
Artikel-Nr.: 420.671-02

Seitenkoffer  
Topcases  
Gepäckträger  
Lock it System  
Softbags  
Aluminiumkoffer  
Lederkoffer  
Schutzbügel  
Hauptständer  
Chopper-Parts  
Accessoires



## Montage

Der Bausatz umfaßt die folgenden Teile:

Stück	Bestellnr.	Bezeichnung	Stück	Bestellnr.	Bezeichnung
1	700008294	Hauptständerplatte			
3	151.407	Rohrschellen ø25mm	4	151.309	Senkscheiben Ø6,4 x Ø18
1	151.023	Senkkopfschraube M6x45	4	150.809	U-Scheibe ø6,4
3	151.102	Senkkopfschraube M6x25	4	150.799	Selbstsichernde Mutter M6



**Nach der Montage alle Verschraubungen auf festen Sitz kontrollieren!**

Artikelnummern für Farbe anthrazit 05  
Teilweise auch in silber und schwarz lieferbar

Als weiteres Zubehör lieferbar:

Kofferträger (Lock it System, abnehmbar)	Art.-Nr.:	650.665 00 05
Gepäckbrücke	Art.-Nr.:	650.665 01 05
Tankschutzbügel	Art.-Nr.:	502.665 00 05
Motorschutzplatte	Art.-Nr.:	810.665

Mehr Zubehör auf unsere Homepage.



**Hepco & Becker GmbH**  
An der Steinmauer 6

D-66955 Pirmasens

Tel.: 06331 - 1453 - 100

Fax: 06331 - 1453 - 120

eMail: [vertrieb@hepco-becker.de](mailto:vertrieb@hepco-becker.de)

[www.hepco-becker.de](http://www.hepco-becker.de)

# Schutzplatte für Original-Hauptständer

BMW R 1200 GS LC  
Artikel-Nr.: 420.665-02

BMW R 1200 GS Adventure ab Bj.2014  
Artikel-Nr.: 420.671-02

Seitenkoffer  
Topcases  
Gepäckträger  
Lock it System  
Softbags  
Aluminiumkoffer  
Lederkoffer  
Schutzbügel  
Hauptständer  
Chopper-Parts  
Accessoires



## Montage

### Vorbereitung:

Zwei Rohrschellen  $\varnothing 25\text{mm}$  an die Querstrebe des Original Hauptständer und eine Rohrschelle an die in Fahrtrichtung rechte Strebe aufstecken.


### Montage:

Die Schutzplatte seitlich am Hauptständer einhängen, so dass sich die Lasche der Platte zwischen beiden Rückholfedern befindet. Die Senkkopfschraube M6x45 mit der Senkscheibe M6 durchstecken und auf der Rückseite mit U-Scheibe  $\varnothing 6,4\text{ mm}$  und selbstsichernde Mutter M6 verschrauben.



Die übrigen Senkkopfschrauben M6x25 zusammen mit den Senkscheiben M6 durch die Bohrungen der Schutzplatte stecken. Von hinten mit einer U-Scheibe  $\varnothing 6,4\text{ mm}$  und selbstsichernden Mutter M6 verschrauben.

Das Schutzblech ausrichten und alle Schrauben anziehen.



## Protection plate for Original centre stand

BMW R 1200 GS LC  
item.-no.: 420.665-02

BMW R 1200 GS Adventure from 2014  
item.-no.: 420.671-02

### Assembling instructions

Side cases  
Top cases  
luggage frames  
Lock it system  
Softbags  
Aluminium luggage  
Leather luggage  
Protection bars  
Center stands  
Chopper parts  
Accessories



The kit includes the following parts:

Quant	item no.	description	Quant	item no.	description
1	700008294	protection plate	4	151.309	countersunk washer Ø6,4 x Ø18
3	151.407	pipe clamp ø25mm	4	150.809	washer ø6,4
1	151.023	countersunk screw M6x45	4	150.799	self-lock nut M6
3	151.102	countersunk screw M6x25			



**Control all screw connections after the assembling for tightness!**

Also available:

Side carrier (Lock it System)

Rear rack (Alurack, can be combined)

Engine guard

Tank guard

More accessories on our website.

Item-No. 650.665 00 05

Item-No. 650.665 01 05

Item-No. 501.665 00 05

Item-No. 502.665 00 05

Part numbers for anthracite 05  
Also available in silver and black



**Hepco & Becker GmbH**  
An der Steinmauer 6  
D-66955 Pirmasens

**Tel.: +49 (0)6331 - 1453 - 100**  
**Fax: +49 (0)6331 - 1453 - 120**  
**eMail: [vertrieb@hepco-becker.de](mailto:vertrieb@hepco-becker.de)**  
**[www.hepco-becker.de](http://www.hepco-becker.de)**

## Protection plate for Original centre stand

BMW R 1200 GS LC  
item.-no.: 420.665-02

BMW R 1200 GS Adventure from 2014  
item.-no.: 420.671-02

Side cases

Top cases

luggage frames

Lock it system

Softbags

Aluminium luggage

Leather luggage

Protection bars

Center stands

Chopper parts

Accessories




### Assembling instructions

#### Preparing:

Attach two pipe clamps  $\varnothing 25\text{mm}$  to the cross member of the original centre stand and one pipe clamp on the right tube in direction of travel.

#### Fastening of the protection plate:

mount the plate, so that the tab on the plate located between two return springs. By inserting the M6x45 countersunk screw with M6 countersunk washer and screw on the back with washer  $\varnothing 6,4\text{ mm}$  and self-locking nut M6.



Attach the remaining countersunk screws M6x25 together with the M6 countersunk washers through the holes of the protection plate. From the rear use washer  $\varnothing 6,4\text{ mm}$  and self-locking nuts M6.

Align the plate and tighten all screws.

